

281-HUNTON-1 | 1-877-HUNTON-1 | www.HuntonDistribution.com



Contents:

Trane Z-Wave Thermostats - 2 Honeywell Home Z-Wave Thermostats - 2 Honeywell Home Wi-Fi Thermostats - 3 Honeywell Home RedLINK® Thermostats - 4 Wireless Thermostat Solutions - 4 Wireless Condenser Solutions - 5 RedLINK[®] Accessories - 5 Non-Connected Thermostats - 6 PTAC / Fan Coil Controls - 6 Thermostat Goofplates & Guards - 7 Wire Reduction Solutions - 7 Wired Thermostat Sensors - 7 Thermostat Wire - 7 TrueZONE® Zoning Systems - 8 TrueZONE[®] Selection Sheet - 9 ERV's (Energy Recovery Ventilators) - 10 Ventilation Dampers - 10 Dehumidifiers - 11



OFF

Thermostats • Zoning • Dehumidification • Ventilation

TRANE Home App Connected Thermostats

Connect your smart comfort system to the app so you can adjust your temperature, set your schedule and monitor your HVAC usage from virtually anywhere.

Diagnostics - With homeowner permission, Trane's Wi-Fi-enabled thermostats send real-time data to the dealer for remotely monitoring the air conditioner, furnace and entire HVAC system.



Model Number	TZON1050AC52ZA	TCONT850AC52UB	TCONT824AS52DB	TCONT724AS42DA	
Trane connected thermostats can		Inter tons of	Value of the	1800- 0.7500 BP ()	Wired Sensor
connect to any Z-Wave platform,	75 °	75° 🚔	75° 🚔	* 75 ′ **	ZSENSAL0400AA
including the Trane Home App	10 mars 10 dillion 10 filmann Canad	Carrier Contrast of States of States	Contra Carta Carta	Ban Ban Kas fr	Remote wired
Trane Home Remote Climate Access	\checkmark	\checkmark	\checkmark	\checkmark	Indoor temp.
Trane Home Connectivity	Wi-Fi or Ethernet	Wi-Fi or Ethernet	Wi-Fi or Ethernet	Wi-Fi or Ethernet	sensor for TZON1050, TCONT850, TCONT824,
Bridge for Z-Wave Devices	Built-In	Built-In	Built-In	Purchased Separately	and TCONT724.
Compatible with Communicating and XV Systems	\checkmark	\checkmark	No	No	Wireless Sensor
Conventional 24v Control	Requires relay panel (BAY24VRP52DC)	Requires relay panel (BAY24VRP52DC)	\checkmark	\checkmark	ZSENS930AW00MAA
Aux Relays for Ventilation/Dehum	Requires relay panel (BAY24VRP52DC)	Requires relay panel (BAY24VRP52DC)	2	1	Remote wireless Indoor temp.
Touchscreen	7" full color	4.3" full color	4.3" full color	4.3" black & white	sensor for
Programmable (days/schedules per day)	7 / 4	7 / 4	7 / 4	7 / 4	TZON1050, TCONT850, and TCONT824.
Heat/Cool Stages	5 / 2	5 / 2	5 / 2	4 / 2	



Conventional 24 Volt HVAC System Interface Relay Panel for ComfortLink[™] Controls -BAY24VRPAC52DC

Provides communicating systems AUX contacts for

 dehumidifier control, ventilation control, or humidifier control
 Allows TZON1050AC52ZA and TCONT850AC52UB to control non-communicating indoor or outdoor units


Controlling a Trane variable speed blower with a 24v thermostat?

Get the most out of your system by using a thermostat with the "BK" terminal for advanced dehumidification functionality. Enjoy the full functionality of Trane variable speed units with the right thermostat!



TCONT824AS52DB TCONT724AS42DA Thermostats

The 824 utilizes air flow reduction (applies only to variable speed blowers) – If BK is connected, the 824 can reduce the system air flow by 30% anytime the indoor RH is higher than the cooling RH target. Air flow reduction is disallowed if the indoor temperature is more than 2°F above the cooling setpoint. Dehumidification is factory enabled in the Installer Settings.



Honeywell Home Z-Wave Thermostats

A Z-Wave Plus certified thermostat designed to work with any Z-Wave compliant controller or gateway for easy programming and automation. The thermostat can be operated in any Z-Wave network together with other certified devices from other manufacturers. All non-battery operated devices (nodes) within the network will act as repeaters regardless of manufacturer to increase reliability of the network. When integrated with the app that controls your Z-Wave controller, it lets you program and control the home's HVAC system as well as control other Z-Wave devices connected to the same controller.



Item	Series	Туре	Stages	Power Method	Dual Fuel	Display Size
TH6320ZW2003	T6 Pro Z-Wave	Programmable	3H/2C	Battery or C Wire	Yes	5.44 sq. in.

Honeywell Home

Wi-Fi Connected Thermostats





Control a Wired Thermostat from a Smartphone/Computer

Two Apps to Choose From:



Honeywell Home App - For a Smarter Home

- Easily control home comfort, security, and awareness from a single app
- Smart home integration with products from brands like Apple, Google, Amazon, and more
- Geofencing automates home/away HVAC settings .

Series	Item	Туре	Stages	Power Method	Dual Fuel	Ventilation Control	Display Size
тс	TH6320WF2003	December	3H/2C	CM/inc	Yes	Yes	6.89 sq. in.
10	TH6220WF2006	Programmable	2H/2C	C Wire	No	No	6.89 sq. in.

T10 Pro Smart Thermostat with RedLINK[®] Room Sensor

- Graphical LCD color touchscreen with multi-room display Up to 20 RedLINK® room sensors can be connected per thermostat
- RedLINK[®] wireless room sensors detect temperature, humidity & motion
- Prioritize rooms Define a desired temperatures, select priority
 - rooms, or base priority on motion

					,		
Series	Item	Туре	Wireless Sensors	Stages	Dual Fuel	Power Method	Display Size
Г10	THX321WFS2001W	Programmable	1 Included	3 Heat / 2 Cool	Yes	C wire	7.27 sq.in.
I TO	C7189R2002	Additional Senso	rs 2-Pack				
	The Honeyw	ell Home Ap	p controls the	e T6 and T2	L0 therm	nostats above	,
	1		i Water Leak				,

WiFi Water Leak & Freeze Detector

- Receive notifications via smart phone
- Reduced risk of water damage with audible alerts •
- 5-ft sensing cable that detects water through entire length Daisy chain extra cables for up to 500' of coverage

Description Item CHW3610W1001 Wi-Fi Water Leak & Freeze Detector YCHW4000W4004 Contractor 4-Pack of CHW3610W1001 CHWES41013 Accessory Cable Sensor (4 ft.)



Stages

3H/2C

Power

C wire



Total Comfort Connect App - Ideal for Residential or Commercial

- View & change HVAC system settings
- . View & set the temperature
- View & control indoor humidity View outdoor temperature and humidity
- Access multiple thermostats if the system is zoned Access multiple locations and systems •

Series

VisionPRO[®] 8000

9000 Smart Color

- Receive temperature and humidity alerts via email
- Access over 90 system alerts via the web



IAQ Relay

Yes

No

Display

10 sq.in.

8 sq.in.

4 - 5,



TH8321WF1001



TH9320WF5003

(No internet gateway is required for these two controls above)
The TCC App also controls the RedLINK [®] thermostats on pages
and the RedLINK [®] zoning systems on pages 6 - 7.

(The THM6000R7001 Gateway is needed for those applications)

Type

Programmable

The Total Comfort Connect App (TCC) controls the two thermostats above

Total Comfort Connect WiFi

Item

TH8321WF1001

TH9320WF5003




RedLINK® Wireless Technology Platform Controls that Serve both Residential and Commercial Applications

During setup select whether the control will be commercial or residential



Strong Light Commercial Functionality

Meets commercial building codes, including Title 24



- .
- .
- Integrates occupancy sensor, lighting controls & other HVAC/IAQ systems •
- Initiate occupancy Save energy in rooms not frequently used Adjustable ramp rates - Initiates early recovery as needed .
- Self-monitoring diagnostics with alerts Integrates occupancy sensors, lighting controls and other HVAC/IAQ systems when using an EIM board



Control with the TCC App! (requires the internet gateway)

VisionPRO[®] 8000 Series

Three Flexible Ways to Install

- Wired directly to the equipment
 2-wire or *wireless* with Equipment Interface Module
 2-wire or *wireless* with TrueZONE[®] zoning systems

an manan manan	Item	Туре	Stages	Power	IAQ Relay	Display
With With Street Cool Outdoor: 207/15X	TH8110R1008	Programmable	1H/1C	Battery & Hardwire	No*	10 sq.in.
630° - 55° , 25°	TH8320R1003	Programmable	3H/2C	Battery & Hardwire	No*	10 sq.in
	TH8321R1001	Programmable	3H/2C	Battery & Hardwire	Yes	10 sq.in



Go Wireless from

* IAQ control is available when the thermostat is paired with an EIM module below

Add the Equipment Interface Module (EIM) to:

Gain additional IAQ/ventilation control contacts and sensor inputs Add upstream/downstream temperature sensors to measure Delta T Place a thermostat on the wall with no wires

- Up to 4H/2C in a heat pump system
- Up to 3H/2C in a conventional system
- Three sets of Universal IAQ contacts to control dehumidification/ventilation
- Four sensor inputs for wired sensors or dry contact devices
- THM4000R1000 can be used to extend the wireless range
- Compatible with all RedLINK[®] devices

Item


Description THM5421R1021 Prestige[®] 2-Wire/VisionPRO EIM Board YTHM5421R1010 EIM Board w/ 2 Duct Sensors



RedLINK[®] Prestige[®] IAQ

Robust capabilities — with a smaller, sleeker profile for design-conscious residential and light commercial end users

- Small sleek design Full-color display Customizable and high-definition •
- Alerts log Stores 25 alerts to help technicians easily determine what part of the system needs attention
- System performance log Min/ max indoor/outdoor temperatures, humidity, run time, and more - organized by hour, day, week or month
- Delta T Provides alerts and diagnostics when system needs service .
- Four assignable inputs Connect wired sensors, remote setback or dry contacts .
- Dealer info Contractor contact information available with the touch of a . button, driving repeat business



Prestige [®] IAQ Kits	Kit Contains	Image
YTHX9421R5085WW	THX9421R5021WW Prestige [®] 2-Wire IAQ Thermostat THM5421R1021 Equipment Interface Module 2 Duct Sensors	2
YTHX9421R5127WW	THX9421R5021WW Prestige [®] 2-Wire IAQ Thermostat THM5421R1021 Equipment Interface Module THM6000R7001 RedLINK [®] Internet Gateway 2 Duct Sensors	

Replacement Stat	Notes
THX9421R5021WW	Does not work as a stand-alone control. Must be used in conjunction with an EIM or wireless zoning adapter.

Go Wireless from the Condenser to the Indoor Unit!



Control the System Online!

RedLINK[®] Equipment Remote Module

Kit Contains

The ERM uses reliable RedLINK[®] technology to let control devices, such as a thermostat, communicate wirelessly with outdoor two-stage air conditioners and heat pumps.

	-	
10	em	

ERM5220R1018	RedLINK [®] Equipment Remote Module
YERM5220R8321	ERM5220R1018 (ERM) & TH8321R1001 (VisionPRO)
YERM5220RVPEIM	ERM5220R1018, TH8321R1001, & THM5421R1021 (EIM)

RedLINK[®] Wireless Accessories

RedLINK[®] Internet Gateway



Wirelessly Connect These Accessories to any RedLINK[®] control!



When the RedLINK® Wireless Indoor Air Sensor is paired with a VisionPRO® or Prestige® 2-wire thermostat the sensor(s) enables changing the sensing location of the thermostat, average temperature in large rooms, or monitoring humidity. • 2 7/8 in. high x 1 7/8 in. wide x 15/16 in. deep

• Wireless & battery operated (2 AAA)

Item Description C7189R1004 RedLINK[®] Wireless Indoor Air Sensor

L	Ann		
C			
С	Vacatio	<u> </u>	

With the RedLINK® Wireless Entry/Exit Remote you can setback and recover thermostat control from anywhere in the building. Comes with commercial and residential cover plates.

- (1) Entry/Exit Remote can control up to (16) thermostats
- Each stat can be linked to up to (3) Entry/Exit Remotes
- 6 1/4 in. high x 3 1/8 in. wide x 1 5/8 in. deep •

Item Description REM1000R1003 Wireless Entry/Exit Remote



HEAT 000L 000

75.

<u>م</u>

The RedLINK® Wireless Outdoor Air Sensor senses outdoor temperature and humidity to display on RedLINK® enabled thermostats and accessories.

- 5 in. high x 3 1/2 in. wide x 1 11/16 in. deep
- Wireless & battery operated (2 AA)

Description Item C7089R1013 RedLINK® Wireless Outdoor Air Sensor

The RedLINK® Portable Comfort Control can view and adjust all RedLINK® thermostats from a single control. Goes anywhere in the building to sense/control temperature. • Controls up to 16 thermostats Touchscreen interface with backlit display

Description

Portable Comfort Control

- Can display outdoor temperature and humidity

	ltem
0.54	4500004004

REM5000R1001

Extend the Range of your RedLINK® Connection with a Wireless Adapter



Connect the Wireless Adapter to an EIM board to extend the wireless range. This is especially recommended in commercial rooftop installations. If the EIM is mounted inside the metal cabinet, it is recommended to use a THM4000R1000 Wireless Adapter for extended wireless range. Mount the Wireless Adapter outside the metal cabinet and connect to the ABCD terminals at the EIM.

> Item Description THM4000R1000 Wireless Adapter for use with RedLINK® enabled thermostats and TrueZONE® system

Honeywell Home Non-Connected Thermostats

Series	Item	Туре	Stages	Dual Fue	Power Method	Display Size	Image
	TH6210U2001		2 Heat / 1 C	ool No			Baseywell-tyre
T6	TH6220U2000	7-Day, 5-2.	2 Heat / 2 C	ool Yes		5.44 sq. in.	530. 72
	TH6320U2008	5-1-1, or	3 Heat / 2 C	ool Yes	Battery or C wire		
ТЛ	TH4110U2005	Non-Programmable	1 Heat / 1 C	ool No		3.93 sq. in.	eccce
T4	TH4210U2002		2 Heat / 1 C	ool No		5.95 Sq. III.	
Series	ltem	Туре		Stages	Power Method	Display Size	Image
	TH3110U2008	3	1 -	leat / 1 Cool			Taquettee
T3		Non-Program		,	Battery or C wire	3.32 sq. in.	<u></u>
	TH3210U2004	1	2 H	leat / 1 Cool			
							Baugued Lane
T1	TH1110D2009) Non-Program	mable 1⊦	leat / 1 Cool	Battery or C wire	2.37 sq.in.	
							Rongwell-core
E1	TH1110E1000) Non-Program	mable 1 H	leat / 1 Cool	Battery or C wire	2.4 sq.in.	8 51
				, = 0000			Caul Dx

Legacy FocusPRO[®] Series

Series	Туре	Item	Display Size	Stages	Power Method	Image	
		TH6110D1005	Standard	1 Hoot / 1 Cool			
$c \circ \circ \circ$	5 4 4 Decemental	TH6110D1021	Large	1 Heat / 1 Cool		Honeywell Home	
6000	5-1-1 Programmable	TH6220D1002	Standard	2 Heat / 2 Cool	bl Battery or C wire		
		TH6220D1028	Large	2 Heat / 2 Cool		A480 0000	
	New Decemental	TH5220D1003	Standard				
5000	Non-Programmable	TH5220D1029	Large	2 Heat / 2 Cool			



See back cover for details

PRU Non-Connected Thermostats

Series	Item	Туре	Stages	Power Method	Display Size	Image	YOUR LOGO 303.555.1234	- Ü	_ I⊧
700	T701	Non-	1 Heat / 1 Cool	Delles and Collins	A en in			ON ALEO	000
/00	T721	Programmable	2 Heat / 1 Cool	Battery or C wire	4 sq. in.		Joe's HVAC		PRU

Simple Private Label Program

Honeywell Home Fan Coil / PTAC Thermostats

MultiPRO[™] Thermostat

SuitePRO[™] Thermostats

Item Number	Changeover	Pipes	Voltage
TB6575A1000	Manual/Automatic	2 or 4 Pipe	120/240v
TB6575B1000	Seasonal/Manual	2 Pipe	120/240v
TB6575C1000	Manual/Automatic	2 or 4 Pipe	120/240/277v
TB8575A1000	Manual/Automatic	2 or 4 Pipe	24v

Accessories	Description
535-34AB08-203	Pipe sensor for 2-pipe changeover
50033847-001	Adapter Plate for Mounting Fan Coil Thermostats to Junction Box

 $\stackrel{\triangle}{\nabla}$

Thermostat Accessories

Cover Plates / "Goof" Plates



Honeywell Home Wired Sensors



Thermostat Guards

Item Number	Туре	Exterior WxHxD	Interior W x H
TG510A1001	Clear Plastic	5 1 x 5 1 x 2 1/2	4 3⁄8 x 4 3⁄8
TG511A1000	Clear Plastic	6 ½ x 7 ½ x 2 ¾	5 x 6
TG512A1009	Clear Plastic	7 ¼ x 9 ¾ x 3 ⅔	5 ⅔ x 8 ⅔
TG511D1004	Beige Metal	6 ½ x 7 ⅔ x 2 ⅔	5 x 6
TG512D1003	Beige Metal	7 ¼ x 9 5⁄8 x 3 ¼	5 ⅔ x 8 ⅔

TG511D1004 TG512D1003 TG510A1001 TG511A1000 TG512A1009



Plenum-Rated Thermostat Wire

For code compliance in ductwork & plenum spaces

ltem #	Gauge	# of Wires	Pack Qty.	
WIR02593	18	2	500' Spool	
WIR02594	18	3	500' Spool	
WIR02595	18	4	250' Spool	
WIR02596	18	5	250' Spool	
WIR02597	18	6	250' Spool	
WIR02598	18	8	250' Spool	



	Item #	Gauge	# of Wires	Pack Qty.
1	WIR02573	18	2	500' Spool
	WIR02574	18	3	500' Spool
	WIR02575	18	4	250' Spool
	WIR02576	18	5	250' Spool
	WIR02577	18	6	250' Spool
	WIR02579	18	8	250' Spool
	WIR02581	18	10	250' Spool


Wire Saver - Use for Wi-Fi and other 24v thermostats when a common wire is needed but not present A wire saver acts as a splitter for applications that do not include a 24-volt C wire. If the system does not include a C wire, install the wire saver in or near the main unit (furnace, air handler) of the system. HVAC Control Board Item Number THP9045A1098

Wire Reduction Solutions



Universal Smart Wire Module 2 to 5 Wire Adapter

- Reduce installation costs by not having to pull additional wire
- Send up to 5 additional outputs over a single pair of wires
- Supports both heat pump and conventional HVAC systems
- Compatible with virtually all major thermostat brands



Honeywell Home TrueZONE® Systems

Customer Demand - The number one HVAC complaint is uneven temperature. More than 60 percent of homeowners will request individual room temperature control in the next home they build.

With the ease, efficiency and cost savings of Honeywell Home zoning solutions, there's no longer a need to zone using two separate systems. The advantages of a one-piece zoning system add up year after year.



Control with the TCC App! (requires the internet gateway)

Wireless Zoning Systems - The Game Changer

When used with RedLINK[®]-enabled TrueZONE[®] panels, the Wireless Adapter allows you to easily — and wirelessly — add zoning to a home or add more zones to an existing system. Most zoning jobs can be done in one day and bidding risk is virtually eliminated.

Add — One Wired; One Wireless

Every home has one room or area that is too hot or cold. Solve that problem with a RedLINK®-enabled TrueZONE® panel and Wireless Adapter Kit. TrueZONE® panels support both wired and wireless thermostats — the choice is yours. Go one wired and one wireless or upgrade all to the Wireless VisionPRO®.

Four Zones Made Effortless and Wireless

When homeowners want zoning, they typically identify more than two zones. With a TrueZONE® HZ432 panel and the Wireless Adapter Kit, add up to four zones (per panel) without running thermostat wires.

Item	Description
THM4000R1000	Wireless Adapter for use with RedLINK® enabled thermo-
	stats and TrueZONE [®] system





Zone Boards

Item	Zones	Stages	V.S. Fan Control	RedLINK Wireless	Included Accessories
HZ311K	3	1H/1C	Yes - BK Terminal	No	(1) transformer and (1) C7735A discharge air temperature sensor
HZ322K	3	2H / 2C	Yes - BK Terminal	With THM4000	(1) transformer and (1) C7735A discharge air temperature sensor
HZ432K	4	3H / 2C	Yes - BK Terminal	With THM4000	(1) transformer and (1) C7735A discharge air temperature sensor



Damper Options

ARD Round Dampers - 2 Wire

- Power close; spring open
- Open and close lights and visual position indicator for quick setup and diagnostics
- Adjustable Range Stops for consistent
- bleed settings
- Push terminals and easy wiring to Honeywell TrueZONE[®] Panel

ltem	Size	Replacement
ARD5TZ	5″	Actuator for all
ARD6TZ	6″	2-Wire Dampers
ARD7TZ	7″	M847D-ZONE
ARD8TZ	8″	IVIO47D-ZUINE
ARD9TZ	9″	
ARD10TZ	10"	
ARD12TZ	12"	
ARD14TZ	14"	
ARD16TZ	16"	
ARD18TZ	18"	
ARD20TZ	20"	

CPRD Bypass Dampers

- Cuts installation time by replacing the old weight system with a simple handle
- Installs at any orientation at any angle
- Provides constant pressure relief regardless of the blower speed

Item	Size	
CPRD8	8″	
CPRD10	10"	
CPRD12	12"	
CPRD14	14"	

MARD Round Dampers - 3 Wire

The MARD series damper is a power opened/power closed zone or bypass damper. It is usually used in light commercial applications on systems larger than 5 tons that do not exceed 2 in. W.C. at the damper, but may be used in any residential system as well.

- Uses 90-second open to closed motor
- Can be used as a zone damper.
- Used with Static Pressure Control (SPC) for bypass applications.

Item	Size	Item Description
MARD6	6″	SPC Adjustable DP Switch
MARD8	8″	
MARD10	10"	
MARD12	12"	
MARD14	14"	and the second
MARD16	16"	Replacement MARD Actuator
MARD18	18"	ML6161B2024



							Heigh	nt					
		6	8	10	12	14	16	18	20	22	24	26	28
	6	ZD6X6TZ	ZD6X8TZ	ZD6X10TZ	ZD6X12TZ	ZD6X14TZ	ZD6X16TZ	ZD6X18TZ	ZD6X20TZ	ZD6X22TZ	ZD6X24TZ	ZD6X26TZ	ZD6X28TZ
	8	ZD8X6TZ	ZD8X8TZ	ZD8X10TZ	ZD8X12TZ	ZD8X14TZ	ZD8X16TZ	ZD8X18TZ	ZD8X20TZ	ZD8X22TZ	ZD8X24TZ	ZD8X26TZ	ZD8X28TZ
	10	ZD10X6TZ	ZD10X8TZ	ZD10X10TZ	ZD10X12TZ	ZD10X14TZ	ZD10X16TZ	ZD10X18TZ	ZD10X20TZ	ZD10X22TZ	ZD10X24TZ	ZD10X26TZ	ZD10X28TZ
	12	ZD12X6TZ	ZD12X8TZ	ZD12X10TZ	ZD12X12TZ	ZD12X14TZ	ZD12X16TZ	ZD12X18TZ	ZD12X20TZ	ZD12X22TZ	ZD12X24TZ	ZD12X26TZ	ZD12X28TZ
_	14	ZD14X6TZ	ZD14X8TZ	ZD14X10TZ	ZD14X12TZ	ZD14X14TZ	ZD14X16TZ	ZD14X18TZ	ZD14X20TZ	ZD14X22TZ	ZD14X24TZ	ZD14X26TZ	ZD14X28TZ
pth	16	ZD16X6TZ	ZD16X8TZ	ZD16X10TZ	ZD16X12TZ	ZD16X14TZ	ZD16X16TZ	ZD16X18TZ	ZD16X20TZ	ZD16X22TZ	ZD16X24TZ	ZD16X26TZ	-
Del	18	ZD18X6TZ	ZD18X8TZ	ZD18X10TZ	ZD18X12TZ	ZD18X14TZ	ZD18X16TZ	ZD18X18TZ	ZD18X20TZ	ZD18X22TZ	ZD18X24TZ	ZD18X26TZ	-
	20	ZD20X6TZ	ZD20X8TZ	ZD20X10TZ	ZD20X12TZ	ZD20X14TZ	ZD20X16TZ	ZD20X18TZ	ZD20X20TZ	ZD20X22TZ	ZD20X24TZ	-	-
	22	ZD22X6TZ	ZD22X8TZ	ZD22X10TZ	ZD22X12TZ	ZD22X14TZ	ZD22X16TZ	ZD22X18TZ	ZD22X20TZ	ZD22X22TZ	ZD22X24TZ	-	-
	24	ZD24X6TZ	ZD24X8TZ	ZD24X10TZ	ZD24X12TZ	ZD24X14TZ	ZD24X16TZ	ZD24X18TZ	ZD24X20TZ	ZD24X22TZ	ZD24X24TZ	-	-
	26	ZD26X6TZ	ZD26X8TZ	ZD26X10TZ	ZD26X12TZ	ZD26X14TZ	ZD26X16TZ	ZD26X18TZ	ZD26X20TZ	-	-	-	-
	28	ZD28X6TZ	ZD28X8TZ	ZD28X10TZ	ZD28X12TZ	ZD28X14TZ	ZD28X16TZ	-	ZD28X20TZ	-	-	-	-

Rectangular Supply Dampers - 2 Wire

Zoning Selection Worksheet

1) Are you going wireless? Not pulling wire to any zone thermostats? Adding wireless sensors?

If you are wirelessly connecting to a zone controller or accessory, you must add the THM4000R1000 wireless adapter. You must also select a H7322K or H7432K in step 2.

Wireless RedLINK [®] Accessories	Part Number	Qty.
$Wireless {\sf Adaptor} ({\sf To enable} {\sf RedLINK}^{\circledast} {\sf thermostats} {\sf and} {\sf accessories})$	THM4000R1000	

2) Choose your TrueZONE[®] panel. For RedLINK[®] compatibility select either the HZ432K or HZ322K.

TrueZONE Panel Kits	Part Number	Qty.
HZ432K -4 zone, 3H/2C panel used for conventional, heat pump or dual-fuel systems; RedLINK [®] enabled. Kit incudes (1) HZ432 panel, (1) transformer and (1) C7735A discharge air temperature sensor.	HZ432K	
HZ332K –3 zone, 3H/2C panel used for conventional or heat pump equipment; RedLINK [®] enabled. Kit incudes (1) HZ432 panel, (1) transformer and (1) C7735A discharge air temperature sensor.	HZ322K	
HZ311K –3 zone, 1H/1C panel used for conventional systems. Kit incudes (1) HZ432 panel, (1) transformer and (1) C7735A discharge air temperature sensor.	HZ311K	

3) Choose your zone dampers

Duct Diameter	Standard Round Damper	Qty.
5" Round Damper	ARD5TZ	
6" Round Damper	ARD6TZ	
7" Round Damper	ARD7TZ	
8" Round Damper	ARD8TZ	
9" Round Damper	ARD9TZ	
10" Round Damper	ARD10TZ	
12" Round Damper	ARD12TZ	
14" Round Damper	ARD14TZ	
16" Round Damper	ARD16TZ	
18" Round Damper	ARD18TZ	
20" Round Damper	ARD20TZ	

4) Choose your bypass damper

Calculate Total CFM, then choose Supply-To-Return Bypass					
	-		=		
Total CFM of system	minus	CFM of smallest zone	equals	Total CFM to bypass	

	Part #	t # Description		
	CPRD8	Bypass up to 600 CFM (replaces 8" & 10" weighted round barometric damper)		
	CPRD10	Bypass up to 1000 CFM (replaces 12" weighted round barometric damper)		
	CPRD12	Bypass up to 1400 CFM (replaces 14" weighted round barometric damper)		
/	CPRD14	Bypass over 1400 CFM (replaces 16" weighted round barometric damper)		

5) Choose a thermostat for each zone

	RedLINK [®] Enabled Thermostats		
Two Wires Required.	Prestige [®] 2-Wire IAQ thermostat with RedLINK [®] technology (white/white). Controls up to 4H/2C heat pump or 3H/2C conventional. Thermostat only.**	THX9421R5021WW	
Wireless Placement Capable!	VisionPRO [®] 8000 with RedLINK [®] Technology. Controls up to 4H/2C heat pump or 3H/2C conventional. Thermostat only.**	TH8320R1003	

6) Choose additional wireless accessories. You must have selected a THM4000R1000 in step 1.

**In order to enable IAQ device control, configurable input sensors, wireless indoor air sensors, and other advanced RedLINK® functionality, enroll the thermostat into a supported equipment interface module, and wire the equipment interface module into the TrueZONE® panel.

Wireless RedLINK [®] Accessories	Part Number	Qty.
EIM Board (for use with Prestige $^{\circ}$ or Vision PRO $^{\circ}$ to control IAQ Products or advanced RedLINK $^{\circ}$ features.)**	THM5421R1021	
RedLINK® Internet Gateway	THM6000R1002	
Personal Comfort Control	REM5000R1001	
Wireless Outdoor Air Sensor	C7089R1013	

Energy Recovery Ventilators (ERVs)

TRANE[®] Energy Recovery Systems



Model Number	CFM	Replacement Filter
EERVR100A1P00B	120	FLR08618
EERVR200A1P00B	200	FLR08619
EERVR300A1P00B	300	FLR08619



- 6" & 8" double collar duct connections for EERVR100 and 200
- 8" round compatible duct connection for EERVR300
- Closed cell foam gasketing for insulation integrity
- 1" duct board insulation with cleanable foil face
- Passive defrost condensate drain not required
- Pressure ports are accessible through front panel without door removal
- "Guillotine" type dampers are included to balance for correct airflow
- Percent Timer (PT) control included for simple, automatic operation

Honeywell Home Balanced Ventilation Systems

ERV Item Number	Description	Replacement Filter Kit
VNT5070E1000	70 CFM Energy Recovery Ventilator	50063805-003
VNT5150E1000	150 CFM Energy Recovery Ventilator	50053952-005
VNT5200E1000	200 CFM Energy Recovery Ventilator	50053952-006

Along with the time-saving installation and simplified balancing, Honeywell Home ventilation systems offers an array of other benefits:

- Removable Duct Collars: Spend less time on the ladder by easily connecting the ductwork to the collars away from the unit before it's hung, and then sliding the collars back into place once ducted.
- Simplified Balancing: Two variable-speed motors one for each air stream work with the integrated speed control so installers can adjust the speed of each motor up and down to easily balance the system. This eliminates the need for adjusting dampers.
- Adjustable Hanging Straps: Just like tightening or loosening straps on a backpack, these straps make it easy to raise, lower and level the unit into place.
- Meets ASHRAE 62.2 Standards: Your assurance of meeting code requirements

Controls



RedLINK® Prestige IAQ®, VisionPRO® TH8321WF1001 / TH8321R1001, or the T10 Pro all provide ventilation control from a single device, effortless programming and a wide range of comfort and energy-saving features.





ASHRAE Ventilation Sizing Chart Table 4.1a (I-P) Ventilation Air Requirements, cfm							
Floor Area	# of Bedrooms						
(ft2)	0 - 1	2 - 3	4 - 5		>7		
< 1500	30	45	60	75	90		
1501 - 3000	45	60	75	90	105		
3001-4500	60	75	90	105	120		
4501 - 6000	75	90	105	120	135		
6001-7500	90	105	120	135	150		
> 7500	105	120	135	150	165		

Fresh Air Dampers & Controls

Honeywell Home

W8150A1001 Ventilation Control

The control operates a fresh air intake damper and, when necessary, activates the main HVAC blower to efficiently meet ASHRAE ventilation rates.

- Designed to help meet local ventilation codes and standards, including the ASHRAE 62.2-2010 standard.
- Smart Control optimizes air delivery by syncing ventilation calls with heating/cooling
- Easy-to-use input dials allow customized ventilation for each installation.
- Test mode that includes immediate feedback to installer to confirm that air delivery requirements of selected ventilation standard are being met.
- Economical supply-only ventilation; works with forced air system.
 Can be used with other equipment, such as an HRV/ ERV, for
- Can be used with other equipment, such as an HKV/ EKV, for balanced ventilation.



EARDTZ Dampers


The EARD is a round damper with a 24v powered-open / spring-closed motor. It is used for fresh air intake for ventilation or for combustion makeup air.

- Front facing display with LED indication light for Open & Close
 Adjustable damper open position range stops
- Shipped as power open/spring return closed (field converts to spring-open/power return)
- Rated to operate up to 1 in. wc
- Simple, easy-to-wire, two-wire installation
- Male (crimped) and female (uncrimped) ends to connect to any rigid or flexible round duct.

Item	Description	Replacement
EARD6TZ	6" Round Fresh Air Damper	
EARD8TZ	8" Round Fresh Air Damper	M847D-VENT
W8150A1001	Fresh Air Ventilation C	Control
Y8150A1017	Fresh Air Ventilation Kit - Includes W8150A1001 control, and a 24	

Honeywell Home Dehumidification Systems

Dehumidification Systems are integrated into your HVAC equipment, which means they're more effective and can be less expensive than putting multiple single-room units in a home. They can also be used as a standalone solution to remove moisture from problem areas, and eliminate the need for maintenance (emptying collection buckets) — all while using less energy compared to most portable dehumidifiers.



Item	Performance	Energy Star	Application	Voltage	Dimensions W x H x L	Replacement Filter	Drain Pan
DR65A3000	65 pints/day at 80°F, 60%RH	No	2-3 Ton or 1800 sq. feet	120v	12" x 12" x 28.5"	50049537-005	18" x 44"
DR90A3000	90 pints/day at 80°F, 60%RH	Yes	3-4 Ton or 2800 sq. feet	120v	14.33" x 19.33" x 32.35"	50070171-002	18" x 44"
DR120A3000	120 pints/day at 80°F, 60%RH	Yes	4-5 Ton or 3600 sq. feet	120v	14.33" x 21.25" x 32.35"	50070171-002	18" x 44"

Use these Honeywell Controls with your Honeywell Whole-Home Dehumidification System					
	···· <u>55. 25</u> . Teachir				
YTHX9421R5085WW	TH8321R1001	THX321WFS2001W/U	H6062A1000		
 Prestige IAQ High-definition, full-color display RedLINK[®] technology and accessories Sliding scale shows actual and desired humidity levels 	VisionPRO 8000 • All-in-one control in the living space • RedLINK® technology and accessories • Smart Schedule programs in seconds	T10 Pro Smart Series Control humidification, dehumidification, or ventilation from thermostat or app Energy savings through scheduling and geo-fencing at thermostat or in app Add RedLINK® Room Sensors to extend reach of thermostat beyond the hallway sensors	 HumidiPRO Humidity Control Manages dehumidification / humidification Simple installation, programming and operation Wired outdoor sensor included Automatically adjusts indoor setting based on outdoor conditions 		





50

Features:

- Wi-Fi and touch screen control for user convenience.
- Fan-only Function. Set for 10, 20, or 30 min. per hour.
- Filter Hour Indicator (replace MERV 11 filter annually)
- Low Temperature ShutoffComfortable handles integrated into both the box and
- the unit for ease of installationAdjustable feet for leveling.
- Safety grates and duct mount collars included

New APP Features:

- Humidity sensor offset (+/-5%): changes calibration of the humidity sensor to match another humidity measuring device in the home.
- Low voltage connection for remote dehumidistat or water leak detection device.
- APP attempts to reconnect should Wi-Fi be lost until connection is restored.
- Freezestat and Dewpoint lockout setpoint.

Set Point 555 % Normal Inference	ltem	Performance	Application	Voltage	Dimensions W x H x L	Replacement Filter	Drain Pan
C (1) Iome	DH75	75 pints/day at 80°F, 60%RH	Up to 3,800 sq. ft.	120v	12.6" x 12.75" x 21"	10" x 12" x 1"	18" x 44"
Settings	DH100	100 pints/day at 80°F, 60%RH	Up to 5,200 sq. ft.	120v	12.6" x 15.75" x 21"	12" x 12" x 1"	18" x 44"

So, why be part of Resideo Pro PERKS?

The Resideo Pro PERKS Loyalty Program offers your company the ability to earn even more with every dollar spent on Resideo products along with a collection of benefits that can help you grow your business.

Become a member now at Pro.Resideo.com



See how P.E.R.K.S. works for you

PERFORMANCE

Earn up to 4% back on your Resideo product purchases! (Tiers: Silver = 2%, Gold = 3%, Platinum = 4%)

ENABLEMENT

Take advantage of our cutting-edge digital marketing platform and receive marketing support training. We'll share tips to help you grow your brand, source new leads, and win new business!

REWARDS

Redeem your Resideo Pro PERKS points towards Product Certificates, Co-Op marketing activities, promotional merchandise, or employee rewards.

KNOWLEDGE

Access Resideo's world-class library of training offerings that includes self-paced, online courses and webinars in addition to live, in-person and virtual classroom training.

SERVICES

Receive the Resideo Pro PERKS monthly newsletter with updates on the latest program benefits, product technical tips, training schedule and much more!



Honeywell Home

PRIVATE LABEL PROGRAM



The Private Label Program gives your customers the best quality thermostat coupled with convenient HVAC service information. They'll know exactly who to call for future HVAC needs — and you'll get their reoccurring business.

The program includes up to three full lines of your personalized information printed onto the thermostat cover, low minimum order quantities, and no annual volume commitment.

To get started go to **<u>customer.resideo.com</u>** and login to your company account.

